

Excited State Absorption Study in Sulfonated-Halogenated Porphyrins

L. De Boni¹, P.J. Gonçalves², C.J.P. Monteiro³,
M. M. Pereira³, S.C. Zilio¹, C. R. Mendonca¹


*1- Instituto de Física de São Carlos, Universidade de São Paulo, Caixa Postal 369, 13560-970
São Carlos, SP, Brazil,*

2- Instituto de Física, Universidade Federal do Goiás, Goiânia, GO, Brasil


3- Departamento de Química, Universidade de Coimbra, Coimbra, Portugal

Motivation


Porphyrins



Photodynamics therapy



Optical Limiter



To obtain wide nonlinear spectra with proper resolution as function of the pH state of the porphyrins.


- ✗ Excited state absorption
- ✗ Excited state life time
- ✗ Population and structural dynamics
- ✗ Triplet state formation

Acid


Basic

Samples


5,10,15,20-*meso*-tetraquis(2-fluor-5-sulfofenil)




5,10,15,20-*meso*-tetraquis(2,6-fluor-3-sulfofenil)



5,10,15,20-*meso*-tetraquis(2-cloro-5-sulfofenil)







5,10,15,20-*meso*-tetraquis(2,6-dicloro-3-sulfofenil)



Changes in pH: basic and acid

Linear absorption




More than
one species

Fluorescence Lifetime

Excitation is done by using a 532nm 70ps laser pulse

Fluorescence signal is collected by using a optical fiber and the time was measured with fast Silicon detector (500ps rise time)




Mono-exponential

	pH	τ_{fl} (ns)
TF	1.4	1.5
TF	11	11.4
TDF	11,9	8.7
TC	1.45	0.9
TC	11,75	2.3
TDC	11,8	0,41*

*Value obtained by ours Collaborators

The Technique


Z-scan technique



Sheik-Bahae, M. et al., IEEE J. Quantum Elect. 1990, 26, 760-769


Decreasing in the Transmittance at the focal point

✓ White light continuum ZS setup




Results



Excited state absorption spectra



Rate equations only for singlet states




σ_{01} and τ_{10} are known




Results



Excited state absorption spectra



Rate equations only for singlet states




σ_{01} and τ_{10} are known






Results

Excited state absorption spectra




Rate equations only for singlet states

σ_{01} and τ_{10} are known




The Pulse Train Z-scan Technique




Applied Physics Letters, 74, 1531-1533 (1999)


Typical Z-scan curve



Fast processes




Accumulative processes





Results

Rate equations considering the triplet states



NOW, σ_{01} , σ_{12} and τ_{10} are known

	pH	σ_{34}	σ_{34}/σ_{01}	τ_{isc} (ns)	ϕ_{isc}
TF	1.4	6,2	4,5	2,2	0,68
TF	11	1,28	2,0	13	0,88
TDF	11,9	0,73	1,4	10	0,87
TC	1.45	2,60	4,4	1,0	0,90
TC	11,75	0,82	1,2	2,5	0,92
TDC	11,8	0,69	1,0	-	-



Conclusion

- Halogenated atoms increases the intersystem crossing yield: **important to PDT**;
 - a weak RSA effect was observed in the singlet transition
 - a considerable enhancement of the RSA effect in the triplet state
- The vibronic structure of the porphyrins (D_{2h} molecular symmetry) is preserved upon electronic excitation;

pH effect

- it is possible to protonate TC and TF;
- Protonation:
 - increases σ_{12}/σ_{01} between 450 to 550 nm;
 - reduces τ_{S1} , τ_{isc} and ϕ_{isc} ;
 - increases σ_{01} , σ_{12} and σ_{34} at 532 nm; pulse train
- Protonation: conformational changes
- The protonation shows a high RSA: potential candidates for applications in optical devices, such as optical limiters.

Acknowledgements



Thank you

